

PART LIST

1.	LEFT HAND SIDE.	1	NO.
2.	RIGHT HAND SIDE.	1	NO.
3.	BACK	1	NO.
4.	TOP	1	NO.
5.	BOTTOM FRONT PIECE	1	NO.
6.	BOTTOM TRAY	1	NO.
7.	SHELF	1	NO.
8.	DOOR	1	NO.
9.	COAT RAIL HOLDER.	2	NOS.
10.	COAT RAIL.	1	NO.
11.	LOCK WITH 2 KEYS.	1	NO.
12.	RIVETS	48	NOS.

FITTING INSTRUCTIONS

REFER SKETCHES ON PAGE 3.

- A. AFFIX COAT RAIL HOLDER, 1 NO. EACH (ITEM NO. 9) TO LEFT HAND SIDE (ITEM NO. 1) AND RIGHT HAND SIDE (ITEM NO. 2).

[RIVETS REQUIRED 4 NOS.]

- B. AFFIX BOTTOM FRONT PIECE (ITEM NO. 5) TO BOTTOM TRAY (ITEM NO. 6).

[RIVETS REQUIRED 2 NOS.]

NOTE— INSERT TOP FLANGE OF THE ITEM NO. 5 BEHIND THE FRONT FLANGE OF THE ITEM NO. 6. (REFER SKETCH A BELOW SHOWING THE RESPECTIVE FLANGES).

- C. AFFIX BACK (ITEM NO. 3) TO LEFT HAND SIDE (ITEM NO. 1) AND RIGHT HAND SIDE (ITEM NO. 2).

[RIVETS REQUIRED 12 NOS.]

NOTE— PLEASE DO NOT USE HOLES ON THE 1ST, 5TH AND THE 8TH ROW, (TOTAL 6 NOS.) OF THE BACK (FROM THE TOP EDGE) AND THE RESPECTIVE HOLES ON BOTH THE SIDES.

THESE HOLES WILL BE REQUIRED LATER FOR FITTING TOP, SHELF AND BOTTOM. (SEE SKETCH BELOW)

- D. INSERT BOTTOM ASSEMBLY IN THE SUB ASSEMBLY C (LEFT HAND SIDE + RIGHT HAND SIDE + BACK) AND AFFIX TO IT.

[RIVETS REQUIRED 8 NOS.]

- E. INSERT SHELF (ITEM NO. 7) IN THE SUB ASSEMBLY D AND AFFIX TO IT.

[RIVETS REQUIRED 4 NOS.]

- F. PLACE TOP (ITEM NO. 4) ON SUB ASSEMBLY E AND AFFIX TO IT.

[RIVETS REQUIRED 12 NOS.]

- G. AFFIX DOOR (ITEM NO. 8) TO SUB ASSEMBLY F. WE SUGGEST TO PLACE THE SUB ASSEMBLY F ON THE GROUND OR A PLATFORM WITH ITS RIGHT HAND SIDE FACING DOWN; THEN INSERT THE FLANGES OF THE HINGES ON THE DOOR IN THE SLOTS PROVIDED ON THE RIGHT HAND SIDE OF THE SUB ASSEMBLY F AND AFFIX TO IT. THEN PLACE THE LOCKER VERTICALLY ON ITS BOTTOM AND INSERT COAT RAIL (ITEM NO. 10) IN THE COAT RAIL HOLDERS ALREADY FITTED TO THE RESPECTIVE SIDES OF THE LOCKER.

[RIVETS REQUIRED 6 NOS.]

